

Durability Index Apparatus SS-18

ASTM D 3744; AASHTO T 210; CALIF. 227, 229

SAFETY INSTRUCTIONS:

Whether you are the owner, employer, operator, or maintenance person for this machine, safety is your responsibility. You are responsible for operating and maintaining this equipment in compliance with these instructions. You should always review and completely understand these safety and operating instructions before using this machine.

Installation and use of the SS-18 Durability Index Apparatus must conform to all OSHA requirements, the national electrical code (NEC), and all local codes.

WARNING!

1. **DANGER!** This machine operates on electrical current. Improper use could result in electric shock, electrocution, injury by explosion, or even death.
2. Voltage and moving parts around motors and motor-driven equipment can cause serious or fatal injuries. **ALWAYS** disconnect power source before working on motor or its connected load.
3. Motor **MUST** be securely and adequately grounded by a method approved by the NEC and by local codes.
4. **DO NOT** use this equipment in a hazardous location as defined by Article 500 of the National Electrical Code (NEC).

INSTALLATION:

1. Installation and use must conform to all OSHA requirements, the National Electrical Code, and all local codes.
2. Choose a location which is not hazardous according to Article 500 of the National Electrical Code.
3. Bolt the SS-18 to the floor or to a rigid table.



SS-18 shown with SSA-22

4. Store unit in a clean, dry, indoor location when not in use.

MAINTENANCE:

Read and completely understand all safety instructions before performing maintenance on the SS-18.

Disconnect power and allow motor to come to a complete stop before performing maintenance or inspection.

- A. Periodically inspect the installation, checking for the following:
 1. Dirt accumulations.
 2. Unusual noises or vibration.

(Continued on back.)

Rev: 05/02/2011

3. Overheating.
4. Worn or loose couplings, sheaves, and belts.
5. High motor current.
6. Overheated electrical connections.
7. Loose mounting bolts.
8. If any of these conditions is present, repair the SS-18 before operation.

- b. Re-oil intermittent duty units every two years.
- c. Re-oil occasional duty units every five years.

3. If you need to use solvents to clean the motor, use **CAUTION**. Some solvents may attack motor insulation, finish, or bearing lubricants. Some are highly flammable. Insure adequate ventilation.

This motor has no thermal protection, so automatic restart is not a hazard.

NOTE: The stroke of the SS-18 is determined by mechanical parts installed at the factory and cannot be changed. Please contact Gilson if you have questions.

B. Even though the materials of construction are chosen to be maintenance-free, periodic cleaning and lubrication will prolong the life of this unit.

1. Grease Nylatron shuffle bearing block and guide rails.
 - a. Use a high-quality, light grease, such as a silicon-based or polyethylene-based lubricant, that will not dry out.
 - b. Grease fittings are provided on either side of the unit, just below the washing vessel platform.
 - c. An alternative to the grease is to remove the grease fittings and use the holes to apply oil (Tri-Flow or Phil Wood Tenacious Oil) to reduce drag on the bearing slide.
2. Apply same oil to the two brass bearings in the base after you have wiped them off with a clean rag.
3. Check belt for wear and proper tension.
4. If you need to use solvents to clean the unit, use **CAUTION**. Some solvents may attack motor insulation, finish, or bearing lubricants. Some are highly flammable. Insure adequate ventilation.

C. Recommended maintenance of motor:

1. Remove dirt accumulation in and around vent openings by vacuuming. Accumulated dirt can cause motor overheating and a resultant fire hazard.
2. Perform periodic re-oiling of the sleeve bearings.
 - a. Use 30—35 drops of SAE non-detergent or electric motor oil. **DO NOT** over lubricate.